











## RAS - Installation Instructions Plus+ Shade 3" Top Fascia Manual

Hardware Included				Tools Required	
					
Self Tapping Screws for Aluminium	Self Tapping Phillips for Tension Device	Brackets	Plastic Connectors	Drill	1/4" Hex Head
			OR		
Wood Screws (If requested)			Metal Stop Balls		Phillips Head
					
			Fascia		


### 1. Install Bracket

Attach the brackets to the window frame, molding, wall or ceiling. Brackets are universal so clutch may be mounted on either side. Two screws must be installed in each bracket.




### 2. Install Shade

Put the spring loaded pin into the round hole of the bracket (A). Keeping the pin end secured in its bracket, insert the hook arms on the clutch straight into the two hook arm receiver holes on the bracket (B). Once the two hook arms are through the holes, gently pull down on the clutch until the two hook arms have locked securely to the bracket. The bottom of the clutch should always point straight down. Shade designed for logo to face exterior.





### 3. Shade Adjustment (If Necessary)

Roll shade up and down to bottom rail is level and material rolls up straight on center tube. If the bottom rail/hembar is not level, lower shade until you see the metal tube. Add layers of masking tape to the metal tube to the end that is too low until bottom rail is straight. If the material tracks to one side, lower shade until you see the metal tube. Add layers of masking tape to the metal tube to the end that is opposite the direction of tracking, until shade rolls up straight.



### 4. Install the Fascia


Slide the top of the fascia (2" side) into the corner openings in the brackets all the way on each side (Fig 1). Gently push the hooked bottom to lock into the bracket. Lock in each side into the brackets (Fig 2).








HARDWARE INCLUDED



Tension Device + Chain



Tension Device Bracket




Short Screws




Screws

TOOLS REQUIRED




3/8" Hex Head



Phillips Head




1/8" Drill Bit



Drill

INSIDE OR OUTSIDE APPLICATION



INSIDE

OUTSIDE

## INSIDE MOUNT & TENSION DEVICE INSTALLATION

Pull the Chainhold down until the chain is fully tensioned (plunger will be fully raised). Screw device into wall.

A

KEEP  
TENSION



B



C

SECURE  
TENSION  
DEVICE




**NOTE:** Please make sure shade operates smoothly.

## OUTSIDE MOUNT & TENSION DEVICE INSTALLATION

With provided screws, install bracket first with large screws (use Chainhold marked screw hole locations as reference). Pull the Chainhold down until the chain is fully tensioned (plunger will be fully raised). Install Chainhold into bracket with small screws.


A

PULL CHAIN  
DOWN &  
MARK  
LOCATION




B


REMOVE  
TENSION  
DEVICE  
& DRILL



C



D




E

PLACE  
TENSION  
DEVICE ON  
BRACKET



F

SECURE  
TENSION  
DEVICE



**NOTE:** Please make sure shade operates smoothly.